





MC-5846


5 min.




1 ABRIR CAPÓ PARA ACCEDER AL MOTOR / OPEN THE BONNET
IN ORDER TO GAIN ACCESS TO THE ENGINE COMPARTMENT.



2 RETIRAR COBERTURA DE PLÁSTICO LIBERANDO DOS CLIPS
FRONTALES / TAKE THE PLASTIC COVER AWAY RELEASING
TWO PLASTIC CLIPS.



3 SACAR EL FILTRO DE SU ALOJAMIENTO MEDIANTE LAS
PESTAÑAS DE LOS EXTREMOS / RETIRE THE USED FILTER
HOLDING IT BY THE TABS LOCATED AT ITS SIDES.



4 INSTALAR NUEVO FILTRO MEDIANTE EL PROCESO INVERSO /
INSTALL THE NEW FILTER REVERSING THE PREVIOUS STEPS.

				APLICACIONES	
País	Marca	Modelo	Motor	Desde	Hasta
CR	Peugeot	406	2.0 16V	2000	2004
CR	Peugeot	406	2.2 16V	2000	2004
CR	Peugeot	406	3.0 24V	2000	2004
CR	Peugeot	406	2.2 HDi	2000	2004

*Recuerde cambiar su Filtro de Cabina o de Polen cada año o cada 15.000 kilómetros.

CR: Costa Rica.